

---

Subject: Re: Who was it didn't have enough bass with 4's and 'Mours?

Posted by [Wayne Parham](#) on Thu, 29 Aug 2002 04:34:46 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

The value called for is 16 ohms, so your 15 ohm part is within tolerance and will work just fine. We glob 'em together just to increase power handling, but your Paramours will only muster a couple of watts. You could have used little half watt resistors and probably been OK. How are

---