

---

Subject: you can try glueing

Posted by [Sam P.](#) on Thu, 05 Sep 2002 23:06:09 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

1x2's around the inside edge. I repaired an old AR2 speaker that way, for the same reason...the t-nuts were coming loose where the TOO THIN plywood edge crumbled. Alternative to flush mounting is build up the front baffle, cork panels work well, even another layer of birch ply or mdf, with holes to clear the woofer and horn flanges. Very strong. Sam

---