

---

Subject: Line level passive crossovers

Posted by [Wayne Parham](#) on Thu, 12 Sep 2002 16:47:22 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

You might want to consider using a passive line level crossover. What you do is to make a crossover with the same circuit topology but scaled 1000x or so, closer to preamp input impedance level. Somewhere around 10k ohms is usually fine. It's an excellent solution, and the components required are tiny.

---