Posted by Wayne Parham on Mon, 23 Sep 2002 01:28:56 GMT View Forum Message <> Reply to Message

I had considered attaching the coils to the connector panel with epoxy, or perhaps tied near them with cables ties similar to the way you've described. But I think one of the best ways would be to use a strain relief wrapped around the coil and fastened to a cabinet panel by screw. You can find strain reliefs that are made to hold a wire tie, and that would be perfect for your application.

Page 1 of 1 ---- Generated from AudioRoundTable.com