Subject: Sam's right.
Posted by Wayne Parham on Sun, 29 Sep 2002 17:01:20 GMT
View Forum Message <> Reply to Message

Attach the two through the woofer cutout. Put the horn in place, and attach the compression driver to it.By the way, how did things go with your cabinetmaker?