

---

Subject: Pro Series 7 Pi-18 answers

Posted by [Wayne Parham](#) on Fri, 04 Oct 2002 04:54:16 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

You'll need 1/4"-20 bolts to mount the horn on the driver. As for mounting to the cabinet, I suggest machine screws and T-nuts:Post some pics when you can, those sound gorgeous!