

---

Subject: now thats what I call timing.

Posted by [ToFo](#) on Thu, 14 Nov 2002 16:49:04 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

You must have wrote that while I was listening to my new pad value. You have hit on some other stuff I didn't think of as well. How does that partial bypass work? Say I have three 47 ohm mills in a stack, I put one of the resistors in series with the cap so the bypass only happens to two of them? I think I get it. Cool! (and let me know if Im wrong)Thanks Sam,Thomas

---