

---

Subject: Driver Spacing Question

Posted by [DRCope](#) on Tue, 17 Dec 2002 13:10:43 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

How close to the upper edge of the cabinet should I position a TAD 1602 if I'm putting a TAD 2001 in a Marintelli horn on top and crossing over in the 800-1600 range? I'm trying to make the transition as seamless as possible. Any thoughts on porting to the front vs. the rear? Centering vs. offsetting? Thanks!

Keep your ears and your mind open.

---