

---

Subject: Re: sounds OK

Posted by [Wayne Parham](#) on Tue, 17 Dec 2002 19:04:02 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I'd line the front panel interior with insulation, and put the woofer and port both on the back panel. In this manner, the front baffle won't act as a reflector, bouncing midrange energies into the port. I'm assuming you're building cornerhorns, as I recall, that's what you're building. If they were bass-reflex boxes, I'd line the rear panel with insulation, and put the woofer and port on the front panel, so it's essentially the same thing but reversed.

---