Subject: 1 pi answer
Posted by Wayne Parham on Mon, 30 Dec 2002 01:08:43 GMT
View Forum Message <> Reply to Message

I'm not sure what might be ailing your system. This is a combination that many people have reported good success with. You really shouldn't need the 20 ohm resistor, but it wouldn't cause this problem either.Try to isolate the problem using a process of elimination. By that I mean try different things and try to isolate where the problem remains. Perhaps you have a bad set of drivers or maybe it's just a misconnection of some sort.