

---

Subject: Re: To attenuate the woofer, just use a resistor or L-Pad

Posted by [Mike C](#) on Mon, 13 Jan 2003 20:27:39 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Thanks For getting back to my question Wayne and Patrick. Wayne should I use an inductor for the woofer in reference to how you designed one into your 1 Pi design? Sorry for so many questions, but this should satisfy what's on my mind. Mike

---