Subject: Re: To attenuate the woofer, just use a resistor or L-Pad
Posted by Mike C on Mon, 13 Jan 2003 20:27:39 GMT
View Forum Message <> Reply to Message

Thanks For getting back to my question Wayne and Patrick.Wayne should I use an inductor for the woofer in reference tohow you designed one into your 1 Pi design?Sorry for so many questions, but this should satisfy whatson my mind.Mike