

---

Subject: Wayne and crossover guys; a little help?

Posted by [BillEpstein](#) on Thu, 16 Jan 2003 21:21:00 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

So I've got these 8 ohm Altec 811/806A's sitting on the 16 ohm JBL 2226J's and the Altecs are kinda "hot" sounding with Wayne's 4 Pi Pro Eminence crossover. And I want to cross at 800 Hz like God and Altec intended. So I get the Eminence PXB 2 800 boards, which is rated at 8 ohms. But my Bud says 8 ohm cross is bad and needs another 16 ohms in parallel with the horn. Okay, I can do that. So now I add maybe 30 (?) ohms to the attenuation coming from the tweeter positive, bypassed by, what, .33, .47 uF to tame the highs? And do I remove the 10uF cap like I did for the Pro? Or should I do something entirely different? Please don't suggest I use Spice; it's me, the dummy, Till.

---