

---

Subject: question

Posted by [wasteh202](#) on Wed, 22 Jan 2003 14:16:41 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I built the 2Pi towers a few weeks back. I mounted the mid/woofer and piezo on the surface by simply cutting the holes in the wood as specified in the plans. In my researching more about DIY speaker building I have noticed that some builders countersink the lip of the driver into the wood so that the driver is pretty flush with the wood at the surface. Is this nessessary or serve to alter the sound coming from the speaker, or is it just a cosmetic preference?

---