Subject: Odds and ends
Posted by Wayne Parham on Wed, 29 Jan 2003 06:14:07 GMT
View Forum Message <> Reply to Message

You're right - the wire with the spool should be attached to the midwoofer. Be sure that the lead positive lead of your connector panel is connected to the positive lead of your tweeter and also the positive lead of your midwoofer, through the inductor. I forget if your kits have the inductor that would be screw mounted or not - If you have a hole on the spool that would fit a small screw, us that to attach the coil to the inside back wall. If not, use automotive weatherstrip glue.