

---

Subject: First-order low-pass for speakers

Posted by [Wayne Parham](#) on Mon, 21 Apr 2003 00:53:45 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

You can make a first-order low-pass filter for your 2226's easily enough - Just put a Zobel damper across the woofer and a series coil will then act as a first-order filter. I like to run 'em straight out, using a series coil without a Zobel in a quasi-first-order arrangement, which is basically no crossover at all. But it's no sweat to make a real first-order filter for these woofers if you want it.

---