

---

Subject: Re: First-order low-pass for speakers

Posted by [spkrman57](#) on Mon, 21 Apr 2003 12:09:16 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Wayne, I must have missed the boat on this one, but I thought using single order crossovers that you don't need zobel, but for higher order crossovers you do, My objective is to run my 2226 at 800hz to match up with my 3rd order crossover on the horns. So I am confused now as to which way to go about it. I imagine I should go back to 2nd order and zobel for the bottom end, maybe I did something wrong the first time I tried to use the 2226's with 2nd order/zobel. Thanks Wayne and regular posters here on this forum, Ron

---