

---

Subject: Re: Answers found! Thanks

Posted by [AskBill](#) on Thu, 08 May 2003 22:54:16 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

As I just wrote to the other Bill, these damned Towers are like a bad houseguest and I don't have time for the Altecs. But I do recall mixing sand and latex paint to coat sandboxes for VPI turntables years ago. It would take a lot of sand to get dampening and you'd have to put it on with a trowel. Speaking of which, what about using Thin Set for ceramic flooring? heavy as hell, trowels on thick, flexible and you can add dye. There ya' go. Oh yeah, the fins are indeed the webs. Just use an angle grinder and as already posted, remove only the welds, fill the gaps with any silicone caulk and paint. With thin-set!

---