Subject: Re: DIY cylinder sub-woofer
Posted by Wayne Parham on Wed, 11 Jun 2003 03:21:51 GMT
View Forum Message <> Reply to Message

R13 is plain old commercial insulation used for temperature and sound control. You can find it in any builder's supply store.