

---

Subject: Re: Theater 4 Pi Driver Screws

Posted by [Larry Acklin](#) on Tue, 15 Jul 2003 09:51:58 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I use 1/4 inch hex head bolts with t-nuts. I mix some jb-weld and use it to seat the t-nut, and to "seal" around the outside of the t-nut flange. I draw the t-nut in using a bolt and washer (no hammering). This works well for me on the PA cabinets. I mount the driver with the 1/4 inch bolts and a washer under the head.Larry Acklin

---