

---

Subject: Thank you... another question

Posted by [wasteh202](#) on Tue, 05 Aug 2003 15:37:59 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

What do you use to keep the LF from these ribbon planars? I might be interested in bi-amping such a driver if it required no XO. Do you know if this will work? What are you using with the ribbon below 1000hz? Thanks

---