Subject: Re: Nonsense?????
Posted by Adam on Wed, 15 Oct 2003 12:45:58 GMT
View Forum Message <> Reply to Message

Damping factor is physics, but you place far too much bearing on subwoofer sound quality on it. In any event, your numbers are *still* reversed. The higher impedance load will if anything give a higher damping factor. Even so, there is no noticable difference between 100 or 200 damping on an amp. Feel free, try an A/B test I guarantee you won't notice a difference... It's not a valid reason to shy away from series wiring.Adam