
Subject: Re: Output impedance and woofers

Posted by peter.azinov@infoparc.com on Thu, 16 Oct 2003 05:54:43 GMT

[View Forum Message](#) <> [Reply to Message](#)

Wayne,thank you for the advice. i feel not bound to the se amps. if the output impedance is not low enough to drive the woofer i would use my current push pull mono blocks with 4x e1519 and plenty of power and low Zout or build a hybrid amp for the bass with mosfet power follower to deliver the current in the ouput stage.yesterday i calculated some horns and they get really big...(i can not use a wall for each channel)i am not sure if there is enough room to fit them in. it would be great if you could send me the plans of the 10 Pi horn.thankspeter