
Subject: Re: Output impedance and woofers

Posted by peter.azinov@infoparc.com on Thu, 16 Oct 2003 05:54:43 GMT

[View Forum Message](#) <> [Reply to Message](#)

Wayne, thank you for the advice. i feel not bound to the se amps. if the output impedance is not low enough to drive the woofer i would use my current push pull mono blocks with 4x 6L519 and plenty of power and low Zout or build a hybrid amp for the bass with mosfet power follower to deliver the current in the output stage. yesterday i calculated some horns and they get really big... (i can not use a wall for each channel) i am not sure if there is enough room to fit them in. it would be great if you could send me the plans of the 10 Pi horn. thankspeter
