Subject: Insulation
Posted by Wayne Parham on Thu, 13 Nov 2003 03:27:34 GMT
View Forum Message <> Reply to Message

Like Bill said, the best bet for R13 is "live-end, dead-end" and if there's too much inside, you'll de-tune the system.