

---

Subject: Re: crossover help

Posted by [Wayne Parham](#) on Thu, 11 Dec 2003 17:34:06 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

When using an Altec horn atop a direct radiator, you'll want some padding of the horns. The attenuator will serve double-duty as the damper circuit and can provide top-octave compensation as well. I'd put a standard Zobel on the midwoofer. Other than that, the second-order network you've described will work just fine if you cross-connect the tweeter, wiring "+" to "-". The tweeter motor and the woofer motor should be aligned vertically, within four inches front to back. That gives you a pretty wide position tolerance window where performance will be good.

---