

---

Subject: No fasteners

Posted by [Mike.e](#) on Mon, 15 Dec 2003 11:44:21 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Thanks bill, So the subsections are simply squeezed together? dont i need to just slightly apply pressure on them laterally to be sure? i think a no screws way would be much more attractive and it doesnt move the panels too..a few kg pressure is enough? so a few bricks, i have those about. i use selleys aquadhere wood glue PVA , works fine for me. Cheers!

home.

---