Subject: Re: Update
Posted by Bill Martinelli on Tue, 16 Dec 2003 02:42:14 GMT
View Forum Message <> Reply to Message

Nice work. I agree with Wayne. The second horn is the better of the two. Draw a line through the middle of the highest spots and the lowest spots. Then measure what you have in deviation. Up and down will be the same since your line is in the middle. Your at plus or minus 3db with that graph from 300-2000. Thats good ground to be covering. Nice going.Bill