
Subject: Re: Modeling stage 7 pi
Posted by [Wayne Parham](#) on Tue, 13 Jan 2004 21:56:02 GMT
[View Forum Message](#) <> [Reply to Message](#)

300Hz. Beyond that point, the walls become reflectors instead of flare walls. So you can essentially forget about horn characteristics above 300Hz and view the system as a direct radiator facing a corner reflector.
