

---

Subject: Re: R-13 placement

Posted by [Wayne Parham](#) on Fri, 16 Jan 2004 04:17:36 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Those look really great, Duncan! In this instance, put the R13 along the front baffle, the side and the top. You can either cut circles around the woofer and tweeter holes, or you can attach the insulation up to the point of the woofer and then stop. But this one has the insulation lining the front baffle, so that it opposes the port.

---