

---

Subject: silly seven cornerhorn question

Posted by [artsybrute](#) on Wed, 21 Jan 2004 15:42:19 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi again.I've got all the wood cut up (except for the doghouse angles) and am running out to Home Depot for the insulation.I understand it should be 2" stuff without backing, which I think is R-13.How does the insulation get attached? The only reference I can find is in the attached link which specifies PL400 Deck Adhesive. What is that, and if I cannot find it what is the generic name for something I could use?Thanks,Len

One for the Fridge post

---