

---

Subject: Attaching R-13 insulation

Posted by [Wayne Parham](#) on Wed, 21 Jan 2004 16:22:59 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

You're right about using R-13. Peel off the water barrier paper and attach it with white glue or with a staple gun. A powerful staple gun will drive the staples in firmly, and does a pretty good job. But if they come unlodged, you'll have them bouncing around inside. Using white glue eliminates that possibility, but it takes longer to do.

---