

---

Subject: Re: silly seven cornerhorn question

Posted by [Duncan McBride](#) on Wed, 21 Jan 2004 18:04:27 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

It's 3M Type 77 spray adhesive. Office Depot should have it too. I use it like contact cement - a good coat on each surface, let it dry until real tacky (but not gooey wet), and stick together. I used a staple in the corners too. An old belt and suspenders man.

---