

---

Subject: 'Nother question

Posted by [BillEpstein](#) on Sat, 20 Mar 2004 15:27:00 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

When they say "purely resistive load" what does it mean? Similar to the Piezo which doesn't require a crossover? If I wanted to use this thang on a Theatre 4 above, say, 8-10,000 Hz what would it need in the way of crossover parts? Would just a 1.5uF Cap do?

B-G Planar "resistive load"

---