Subject: Re: Source Impedance Posted by Wayne Parham on Sat, 10 Apr 2004 06:19:38 GMT View Forum Message <> Reply to Message

I think the easiest way would be with a test resistor, oscilloscope and signal generator. You could measure current using the voltage drop and compare with open circuit output. While you're there you could find bandwidth and other specs.

Page 1 of 1 ---- Generated from AudioRoundTable.com