Subject: Re: PI studio series 2 tower
Posted by Wayne Parham on Thu, 15 Apr 2004 08:08:20 GMT
View Forum Message <> Reply to Message

There is no soldering required. After you have the cabinets, you just connect the drivers and bolt them in. So if you're comfortable with you ability to built a box and cut a few holes in it, this kit will be no trouble for you.