

---

Subject: Re: PI studio series 2 tower

Posted by [Wayne Parham](#) on Thu, 15 Apr 2004 08:08:20 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

There is no soldering required. After you have the cabinets, you just connect the drivers and bolt them in. So if you're comfortable with you ability to built a box and cut a few holes in it, this kit will be no trouble for you.

---