

---

Subject: Re: studio 2 non tower

Posted by [Wayne Parham](#) on Thu, 27 May 2004 17:23:05 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Yes, put R13 on the bottom, back and one side. Cut a section flush with the panel it will be attached to so that it covers it fully but isn't bunched up. Remove the paper vapor barrier and glue or staple it in place.

---