

---

Subject: Re: more altec pi issues

Posted by [Tightwad](#) on Fri, 16 Jul 2004 17:46:54 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I like bolting the drivers to the front baffle. Just a regular metal washer between the nut and the wood. For attaching the baffle to the enclosure, I would use threaded inserts, if you have enough wood. In both cases, use locktite (or equivalent). A reasonable hardware store ought to have black bolts. Ask the dude about it, they might be stashed away somewhere out of sight.

---