Subject: Crap bought a bunch of worthless crossover parts Posted by James W. Johnson on Sat, 17 Jul 2004 02:19:49 GMT View Forum Message <> Reply to Message

I thought I needed 10 8 ohm 10 watt resistors to make an 80hm 100watt part...I used the same thinking for all of them. :(these Eagle resistors were a buck each...what a waste.What in the heck do I really need here, I am having trouble with the math here.thanks

Page 1 of 1 ---- Generated from AudioRoundTable.com