

---

Subject: Re: hornresp question

Posted by [Wayne Parham](#) on Thu, 11 Nov 2004 03:26:00 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I think you'll really like 'em. Efficiency will be highest down low, but cone flex modes will add energy above 500Hz. You can crossover below that if you want to run them in their piston range, or you can go with a driver that is well-behaved through the midrange and move the crossover up, making it a wide-range system.

---