

---

Subject: Re: Mounting H290 flare ( with driver attached) to front baffle.

Posted by [Wayne Parham](#) on Mon, 22 Nov 2004 16:24:24 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi Frank, Use T-Nuts if you can. Those H290 mounting holes are close to the edge of the cutout because the lip on the H290 is kind of narrow. Wood screws will hold it, but if you ever go back in, each time those screws are removed and re-inserted takes some of the wood. T-Nuts are a much more durable fastening method. Wayne

---