
Subject: Re: Mounting H290 flare (with driver attached) to front baffle.
Posted by [GarMan](#) on Mon, 22 Nov 2004 17:08:15 GMT

[View Forum Message](#) <> [Reply to Message](#)

No. 10 bolts and T-nuts will work. For attaching the horn on the front baffle, the bottom screws do all the work.If you want a big challenge, you can flush mount the horns into the baffle.Gar.
