
Subject: Re: Mounting H290 flare (with driver attached) to front baffle.

Posted by [Bill Martinelli](#) on Tue, 23 Nov 2004 02:54:19 GMT

[View Forum Message](#) <> [Reply to Message](#)

Your going to love these when you get them fired up. For mounting the H-290 horn. Like the guy's say, T-nuts are very helpful especially in MDF. Make your Baffle cut out for the horn 4.750 tall by 9.625 wide. The horn will fit perfectly and just tip the driver slightly to get it in the opening. Bill
