Subject: You've got mail! Posted by Wayne Parham on Sun, 16 Jan 2005 03:12:47 GMT View Forum Message <> Reply to Message

When using passive networks for tweeter horn compensation, you really can't reduce attenuation without also reducing augmentation up high. So there's a limit to how much can be done. For what you're wanting, I'd suggest you go full active and EQ the tweeter level up some in the top couple of octaves.