

---

Posted by [Bill Wassilak](#) on Fri, 08 Jul 2005 18:02:13 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Just one thing try to get the width down to 30" max. that's the size of most commercial doorways otherwise it'll have to be a permanent install cabinet because you won't be able to move it in or out of buildings. Even 30" is a real tight squeeze through doors. Bill W.

---