Subject: Re: If you must
Posted by Bill Epstein on Thu, 01 Sep 2005 20:23:08 GMT
View Forum Message <> Reply to Message

Get a 3/8 rabbett bit for your router or a dado set for the table saw and make the entire back an access.Rout or dado 3/8x3/8 rabbets on both the rear panel and the rear opening so one fits into the other, Then apply a single strand of rope caulk all the way around. Screw it down.Lots of test cuts on scrap until it's just right.