

---

Subject: Re: If you must

Posted by [Bill Epstein](#) on Thu, 01 Sep 2005 20:23:08 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Get a 3/8 rabbett bit for your router or a dado set for the table saw and make the entire back an access. Rout or dado 3/8x3/8 rabbets on both the rear panel and the rear opening so one fits into the other, Then apply a single strand of rope caulk all the way around. Screw it down. Lots of test cuts on scrap until it's just right.

---