Subject: Re: Nothing
Posted by Wayne Parham on Thu, 01 Sep 2005 21:17:43 GMT
View Forum Message <> Reply to Message

You could also have a go at measuring the T/S parameters. You don't need specializd test equipment and can obtain reasonably good data with your PC (as a signal generator) and a good DVM. See the post called "T/S Measurements" for a write up on this process.