Subject: Re: ** Pi chart request **
Posted by Wayne Parham on Fri, 07 Oct 2005 03:10:11 GMT
View Forum Message <> Reply to Message

Impedance at low frequencies will drop at some points, but will rise again at the resonance modes. At these frequencies, shunt impedance will reduce Zmax and it will tend to remain more constant. It's a consequence that acts in your favor.